

Technical Newsletter

#tnl2015-0018e

1 / 1




Please Do Not Continue Forcibly Turning Flowmeter Knob to the Right

Important note when using flowmeter

When stopping the water by turning the flowmeter knob, please do not turn the knob even further to the right. If you continue turning the knob to the right with excessive force, there is a risk that the interior fastener will fall off, the flowmeter knob section will come loose, and water will pour out of the section that has come loose.

DISCO's flowmeters are intended for adjusting the flow rate. They should not be used as a substitute for the facility-side water-stopping valve.



If you continue forcibly turning knob to the right, this section may come loose.

Inquiries

Please contact your local DISCO sales representative or customer engineer if you have any questions regarding this matter.
